

Cuisinart® 360° 3-IN-1 CHEESE GRATER

Perfect for prep or serving at the table.

3 Grating Surfaces

Fine, medium, coarse sizes

Rotate base to change grater

Durable stainless steel

Grate right over food or into cheese catcher

Protective blade cover

Grater pulls apart for easy cleanup

Dishwasher safe

Lifetime warranty

FRONT

CTG-00-RCG

The Most Trusted Name in the Kitchen®


Cuisinart® 360° 3-IN-1 CHEESE GRATER



1) Remove blade cover.

2) Turn dial to expose desired grate plate.

3) Remove cheese catcher to grate over food, or leave catcher on to collect grated cheese.



Use and Care

Align arrows at base to remove grating cylinder.
Dishwasher safe. Hand-wash for best results.

Lifetime Warranty

For complete warranty information,
please visit www.cuisinart.com

© 2016 Cuisinart
150 Milford Road, East Windsor, NJ 08520
Made in China CTG-00-RCG
16CT022667

CTG00RCG-320

BACK