



USING THE CHOPPING CUP


1. Add ingredients into the cup as recommended in the recipe. Attach chopping blade assembly to the cup.



2. Place cup onto the base. The unit is now powered and in Standby mode with the Power LED illuminated. Press desired speed. When done chopping, press the activated speed to stop.



3. Lift the cup from the base, unscrew the blade assembly and empty the ingredients.



QUICK REFERENCE GUIDE

Cuisinart®

15-Piece Compact Portable Blending/Chopping System


IMPORTANT

Do not throw away. Read before operating your new Compact Portable Blender. Keep for future reference.


These helpful hints are intended to be a supplement to the Instruction Booklet. In order to ensure safe operation and optimum performance, please read the entire Instruction Booklet.

UNPACKING

1. Make sure to remove all packaging tape, stickers and polybags. Wash and dry all parts.




2. Place blender base on flat surface and plug unit into a grounded outlet.




Setup instructions continued inside

USING THE BLENDER JAR


1. Attach blending blade assembly onto the bottom of the jar. Add ingredients, place cover with measured pour lid onto top of jar.



2. Place jar onto the base. The unit is now powered and in Standby mode with the Power LED illuminated. Press desired speed. When done blending, press the activated speed to stop.




3. Lift the jar from the base, take off lid and empty the ingredients.




USING THE TRAVEL CUPS

1. Add ingredients into the cup as recommended in the recipe. Attach blade assembly to the cup.



2. Place jar onto the base. The unit is now powered and in Standby mode with the Power LED illuminated. Press desired speed. When done blending, press the activated speed to stop.



3. Lift the cup from the base, unscrew the blade assembly and attach the travel cup lid.

